

Wiper drive Arm:

Remove the BMW skuttle trim to reveal the wiper arms. The one you want to shorten is the first one that attaches to the motor drive. The two wiper arms just 'pop off' the ball joints with a little leverage. The picture below shows the overall length of the modified arm. Cut it in the middle and remove the required amount of metal. If you are welding it yourself, be sure to 'V' the joint and weld both sides. Mask the polished ball joint end when welding so you don't get any spatter lodged in it too. Simple!



Wiper Arms

Once all the trims are in place, you'll need to tweak the wiper arms for best alignment so don't rush to paint them until that's done.

Wiper blades.

I buy 16" stainless blades off ebay and if need be, cut the big wind deflector off...

Edge Trim

Ebay, Woolies trim or Car Builder Solutions all sell similar 17mm wide stick on half moon plastic trim. Take your time to mitre the joints and if you're clever, PU sealant makes a good rubber seal effect. Take your time with that though and use plenty of masking tape.

Good luck, and don't forget where you got all this handy advice from!